

Switches & Control Gear


Power Rocker Switch

Detailed product specifications are available on: us.100y.com.tw



FEATURES

- The upper and lower bases of $\Phi 22/\Phi 25/\Phi 30$ series can be push-button assembled or disassembled as per our patent. Upper base, fixed base and contact are three detachable parts.
 - Unique modular design of contact blocks keeps internal parts from falling apart when contact blocks are disassembled or replaced.
 - Can assemble or disassemble contact blocks to suit for various models yet without risking excessive stock.
 - Contact blocks can be added click-on easily, no need to unscrew.
 - Connecting screws are fastened from the back rather than normally from the side. It makes wiring easier.
 - A special design to keep connecting terminals and screws in the contact blocks can prevent users from electric shocking.
 - All the connecting pieces of terminals are covered to avoid from electric shocking.
- Capacities are differentiated by colors of contact blocks: blue for 10A; gray for 16A and black for 25A.



HANDLE

S: Short handle


K: Key

| Part No. | Product No. | Manufacturer | Description | Size | V/VAC |
|----------|-------------|--------------|---|---------------|-------|
| 43477 | TCS3K11 | TEND | TEND_ $\Phi 30(10A)$ multistage type cut switch one level (key) | $\Phi 30$ KEY | 10A |
| 43478 | TCS3K12 | TEND | TEND_ $\Phi 30(10A)$ multistage type cut switch two levels(key) | $\Phi 30$ KEY | 10A |
| 43480 | TCS3K13 | TEND | TEND_ $\Phi 30(10A)$ multistage type cut switch three levels(key) | $\Phi 30$ KEY | 10A |
| 43481 | TCS3K14 | TEND | TEND_ $\Phi 30(10A)$ multistage type cut switch four levels(key) | $\Phi 30$ KEY | 10A |
| 43482 | TCS3K15 | TEND | TEND_ $\Phi 30(10A)$ multistage type cut switch five levels(key) | $\Phi 30$ KEY | 10A |
| 43483 | TCS3K16 | TEND | TEND_ $\Phi 30(10A)$ multistage type cut switch six levels(key) | $\Phi 30$ KEY | 10A |
| 43484 | TCS3K17 | TEND | TEND_ $\Phi 30(10A)$ multistage type cut switch seven levels(key) | $\Phi 30$ KEY | 10A |
| 43485 | TCS3K18 | TEND | TEND_ $\Phi 30(10A)$ multistage type cut switch eight levels(key) | $\Phi 30$ KEY | 10A |
| 43505 | TCS3K21 | TEND | TEND_ $\Phi 30(16A)$ multistage type cut switch one level (key) | $\Phi 30$ KEY | 16A |
| 43506 | TCS3K22 | TEND | TEND_ $\Phi 30(16A)$ multistage type cut switch two levels(key) | $\Phi 30$ KEY | 16A |
| 43507 | TCS3K23 | TEND | TEND_ $\Phi 30(16A)$ multistage type cut switch three levels(key) | $\Phi 30$ KEY | 16A |
| 43508 | TCS3K24 | TEND | TEND_ $\Phi 30(16A)$ multistage type cut switch four levels(key) | $\Phi 30$ KEY | 16A |
| 43509 | TCS3K25 | TEND | TEND_ $\Phi 30(16A)$ multistage type cut switch five levels(key) | $\Phi 30$ KEY | 16A |
| 43510 | TCS3K26 | TEND | TEND_ $\Phi 30(16A)$ multistage type cut switch six levels(key) | $\Phi 30$ KEY | 16A |
| 43511 | TCS3K27 | TEND | TEND_ $\Phi 30(16A)$ multistage type cut switch seven levels(key) | $\Phi 30$ KEY | 16A |
| 43513 | TCS3K28 | TEND | TEND_ $\Phi 30(16A)$ multistage type cut switch eight levels(key) | $\Phi 30$ KEY | 16A |
| 43528 | TCS3K31 | TEND | TEND_ $\Phi 30(25A)$ multistage type cut switch one level | $\Phi 30$ KEY | 25A |
| 43529 | TCS3K32 | TEND | TEND_ $\Phi 30(25A)$ multistage type cut switch two levels | $\Phi 30$ KEY | 25A |
| 43533 | TCS3K36 | TEND | TEND_ $\Phi 30(25A)$ multistage type cut switch six levels | $\Phi 30$ KEY | 25A |
| 43534 | TCS3K37 | TEND | TEND_ $\Phi 30(25A)$ multistage type cut switch seven levels | $\Phi 30$ KEY | 25A |
| 43535 | TCS3K38 | TEND | TEND_ $\Phi 30(25A)$ multistage type cut switch | $\Phi 30$ KEY | 25A |



FEATURES

- The upper and lower bases of $\Phi 22/\Phi 25/\Phi 30$ series can be push-button assembled or disassembled as per our patent. Upper base, fixed base and contact are three detachable parts.
 - Unique modular design of contact blocks keeps internal parts from falling apart when contact blocks are disassembled or replaced.
 - Can assemble or disassemble contact blocks to suit for various models yet without risking excessive stock.
 - Contact blocks can be added click-on easily, no need to unscrew.
 - Connecting screws are fastened from the back rather than normally from the side. It makes wiring easier.
 - A special design to keep connecting terminals and screws in the contact blocks can prevent users from electric shocking.
 - All the connecting pieces of terminals are covered to avoid from electric shocking.
- Capacities are differentiated by colors of contact blocks: blue for 10A; gray for 16A and black for 25A.



HANDLE

S: Short handle

K: Key

| Part No. | Product No. | Manufacturer | Description | Size | V/VAC |
|----------|-------------|--------------|--|-----------|-------|
| 43462 | TCS3S11 | TEND | TEND_ $\Phi 30(10A)$ multistage type cut switch one level | $\Phi 30$ | 10A |
| 43464 | TCS3S12 | TEND | TEND_ $\Phi 30(10A)$ multistage type cut switch two levels | $\Phi 30$ | 10A |
| 43465 | TCS3S13 | TEND | TEND_ $\Phi 30(10A)$ multistage type cut switch three levels | $\Phi 30$ | 10A |
| 43466 | TCS3S14 | TEND | TEND_ $\Phi 30(10A)$ multistage type cut switch four levels | $\Phi 30$ | 10A |
| 43467 | TCS3S15 | TEND | TEND_ $\Phi 30(10A)$ multistage type cut switch five levels | $\Phi 30$ | 10A |
| 43468 | TCS3S16 | TEND | TEND_ $\Phi 30(10A)$ multistage type cut switch six levels | $\Phi 30$ | 10A |
| 43475 | TCS3S17 | TEND | TEND_ $\Phi 30(10A)$ multistage type cut switch seven levels | $\Phi 30$ | 10A |
| 43476 | TCS3S18 | TEND | TEND_ $\Phi 30(10A)$ multistage type cut switch eight levels | $\Phi 30$ | 10A |
| 43496 | TCS3S21 | TEND | TEND_ $\Phi 30(16A)$ multistage type cut switch one level | $\Phi 30$ | 16A |
| 43497 | TCS3S22 | TEND | TEND_ $\Phi 30(16A)$ multistage type cut switch two levels | $\Phi 30$ | 16A |
| 43499 | TCS3S23 | TEND | TEND_ $\Phi 30(16A)$ multistage type cut switch three levels | $\Phi 30$ | 16A |
| 43500 | TCS3S24 | TEND | TEND_ $\Phi 30(16A)$ multistage type cut switch four levels | $\Phi 30$ | 16A |
| 43501 | TCS3S25 | TEND | TEND_ $\Phi 30(16A)$ multistage type cut switch five levels | $\Phi 30$ | 16A |
| 43502 | TCS3S26 | TEND | TEND_ $\Phi 30(16A)$ multistage type cut switch six levels | $\Phi 30$ | 16A |
| 43503 | TCS3S27 | TEND | TEND_ $\Phi 30(16A)$ multistage type cut switch seven levels | $\Phi 30$ | 16A |
| 43504 | TCS3S28 | TEND | TEND_ $\Phi 30(16A)$ multistage type cut switch eight levels | $\Phi 30$ | 16A |
| 43520 | TCS3S31 | TEND | TEND_ $\Phi 30(25A)$ multistage type cut switch one level | $\Phi 30$ | 25A |

