

Switches & Control Gear

Power Rocker Switch

Detailed product specifications are available on: us.100y.com.tw

| Part No. | Product No. | Manufacturer | Description | Size | V/VAC |
|----------|-------------|--------------|---|--------|-------|
| 43521 | TCS3S32 | TEND | TEND_Φ30(25A) multistage type cut switch two levels | Φ30 | 25A |
| 43522 | TCS3S33 | TEND | TEND_Φ30(25A) multistage type cut switch three levels | Φ30 | 25A |
| 43530 | TCS3S33 | TEND | TEND_Φ30(25A) multistage type cut switch three levels | Φ30KEY | 25A |
| 43523 | TCS3S34 | TEND | TEND_Φ30(25A) multistage type cut switch four levels | Φ30 | 25A |
| 43531 | TCS3S34 | TEND | TEND_Φ30(25A) multistage type cut switch four levels | Φ30KEY | 25A |
| 43524 | TCS3S35 | TEND | TEND_Φ30(25A) multistage type cut switch five levels | Φ30 | 25A |
| 43532 | TCS3S35 | TEND | TEND_Φ30(25A) multistage type cut switch five levels | Φ30KEY | 25A |
| 43525 | TCS3S36 | TEND | TEND_Φ30(25A) multistage type cut switch six levels | Φ30 | 25A |
| 43526 | TCS3S37 | TEND | TEND_Φ30(25A) multistage type cut switch seven levels | Φ30 | 25A |
| 43527 | TCS3S38 | TEND | TEND_Φ30(25A) multistage type cut switch eight levels | Φ30 | 25A |



Model designation

| | | | | | | | |
|-----|---|---|-----|---|---|------|---|
| TCS | 4 | S | 242 | - | 2 | 2209 | R |
| | ① | ② | ③ | | ④ | ⑤ | ⑥ |

| Designation | Signal | Description |
|---------------------------------------|---------|---|
| 1. Size | 4 | 48*48 |
| | 6 | 64*64 |
| 2. Handle | S | Short handle |
| | L | long handle |
| | O | Octagonal handle |
| 3. Position, turn angle, plate number | 240~842 | --- |
| 4. Capacity | 1 | 10A |
| | 2 | 16A |
| | 3 | 25A |
| 5. Wiring diagram number | | --- |
| 6. Operation | None | Hold |
| | R | Spring return (45°, 2 position, 3 position only) |

| Part No. | Product No. | Manufacturer | Description | Size | V/VAC |
|----------|-------------|--------------|---|-------|-------|
| 43356 | TCS4S33 | TEND | TEND_48*48(25A) multistage type cut switch three levels | 48*48 | 25A |
| 43357 | TCS4S34 | TEND | TEND_48*48(25A) multistage type cut switch four levels | 48*48 | 25A |
| 43358 | TCS4S35 | TEND | TEND_48*48(25A) multistage type cut switch five levels | 48*48 | 25A |
| 43359 | TCS4S36 | TEND | TEND_48*48(25A) multistage type cut switch six levels | 48*48 | 25A |




Model designation

| | | | | | | | |
|-----|---|---|-----|---|---|------|---|
| TCS | 4 | S | 242 | - | 2 | 2209 | R |
| | ① | ② | ③ | | ④ | ⑤ | ⑥ |

| Part No. | Product No. | Manufacturer | Description | Size | V/VAC? |
|----------|-------------|--------------|---|-------|--------|
| 43371 | TCS6S16 | TEND | TEND_64*64(10A) multistage type cut switch six levels | 64*64 | 10A |
| 43373 | TCS6S17 | TEND | TEND_64*64(10A) multistage type cut switch seven levels | 64*64 | 10A |
| 43374 | TCS6S18 | TEND | TEND_64*64(10A) multistage type cut switch eight levels | 64*64 | 10A |
| 43375 | TCS6S21 | TEND | TEND_64*64(16A) multistage type cut switch one level | 64*64 | 16A |
| 43376 | TCS6S22 | TEND | TEND_64*64(16A) multistage type cut switch two levels | 64*64 | 16A |
| 43377 | TCS6S23 | TEND | TEND_64*64(16A) multistage type cut switch three levels | 64*64 | 16A |
| 43378 | TCS6S24 | TEND | TEND_64*64(16A) multistage type cut switch four levels | 64*64 | 16A |
| 43379 | TCS6S25 | TEND | TEND_64*64(16A) multistage type cut switch five levels | 64*64 | 16A |
| 43390 | TCS6S38 | TEND | TEND_64*64(25A) multistage type cut switch eight levels | 64*64 | 25A |



| Item | Code | Description |
|---------------|-------|------------------------------------|
| Control style | VS 33 | Current Switching (3-phase 3-wire) |
| | VS 34 | Current Switching (3-phase 4-wire) |
| Shape | 4 | 48*48 |
| | 6 | 64*64 |
| Capacity | 1 | 10A |
| | 2 | 16A |
| | 3 | 25A |



| Part No. | Product No. | Manufacturer | Description | Size | V/VAC |
|----------|-------------|--------------|------------------------------------|-------|-------|
| 43273 | TVS33-41 | TEND | TEND_48*48(10A) Voltage cut switch | 48*48 | 10A |
| 43278 | TVS33-42 | TEND | TEND_48*48(16A) Voltage cut switch | 48*48 | 16A |
| 43224 | TVS33-61 | TEND | TEND_64*64(10A) Voltage cut switch | 64*64 | 10A |
| 43248 | TVS33-62 | TEND | TEND_64*64(16A) Voltage cut switch | 64*64 | 16A |
| 43253 | TVS33-63 | TEND | TEND_64*64(25A) Voltage cut switch | 64*64 | 25A |
| 43217 | TVS3343 | TEND | TEND_48*48(25A) Voltage cut switch | 48*48 | 25A |
| 43274 | TVS34-41 | TEND | TEND_48*48(10A) Voltage cut switch | 48*48 | 10A |

